9W deep anti-glare RGB+CCT downlight

Model No.：FUT078

Product Feature

- Deep plastic enclosure with best anti-glare performance,UGR≤19
- Dimmable RGB and CCT (2700-6500K)
- 2.4G wireless transmission technology
- smooth dimming with 4096 level, mini brightness 0.1%
- Auto-forwarding: Automatically forward the remote control signal to anothe master box, making the remote control distance infinite
- Auto-synchronization: The same dynamic pattern is automatically synchroniz to keep the pattern consistent
- Have DND function, usually used in power failure area and save power
- Support TUYA SMART app control (2.4G gateway is needed)
- Support third party voice control like Alexa, Google assistant,Yandex Alice, Tmall Genie,Baidu and Xiaomi

Product Parameter

Product Name：	9W deep anti-glare RGB+CCT downlight	IP rate：	IP20
Model No.:	FUT078	Working Temperature：	-10~40℃
Input voltage:	AC100~240V 50/60Hz	Hole Size：	60mm
Power:	9W	Dimming Level：	4096
Power factor：	＞0.5	Dimming Range：	0.1-100%
CRI：	＞90	Dimming Curve：	logarithm
Color temperature：	2700~6500K	EMC Standard (EMC)：	ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-3 V2.3.2
Luminous Flux：	550LM		
Luminous efficiency：	60LM/W	Security Standard（LVD）：	ET IEC 60598-1:2021+A11:2022 EN 60598-2-2: 2012 EN IEC 62031:2020+A11:2021 EN 62498:2015+A1:2022
Beam Angle:	24°		
Protocol:	2.4GHz RF	Radio equipment（RED）：	ETSI EN 300 440 V2.2.1
Control Distance:	30M	Certification	CE, EMC, LVD, RED

Dimension

Installation Tips

① Turn off mains

OFF
ON

② Cut hole in right size

Ø60mm

③ Connect driver with AC100-240V

Driver IP20

④ Lift the spring and insert the light into hole

⑤ Turn on mains and check status of light

OFF
ON

⑥ Don't cover it by thermal insulation material

130mm

Lighting source can not be replaced, please buy new light if the light is over lifetime

Auto-forwarding & Auto-synchronization

Remote control signal auto-forwarding

The remote control signal received by the host will be forwarded to another host within 30m, making the control distance infinite.

Dynamic mode auto-synchronization

In the same dynamic mode, the lamps will be automatically synchronized so that the dynamic effects are always consistent.

Auto-forwarding & Auto-synchronization

Light | Distance 30m | Light • • •

Link/Unlink

turn off light 10 seconds and turn on again

short press " | " 3 times within 3 seconds

link is done once light flashes 3 times slowly

⚠ Link is failed if light doesn't flash, please repeat above steps
(Attention: can not link again if remote already finished linking)

Unlink:

turn off light 10 seconds and turn on again

short press " | " 5 times within 3 seconds

link is done once light flashes 10 times quickly

⚠ Unlink is faild if light doesn't flash, please repeat above steps
(Attention: no need to unlink if the light never be linked)

Compatible Remote (purchase separately)

B8

B0

B3 / B3-B / T3

B4 / B4-B / T4

S2-B / S2-W
S2-G

S2W+

S1W+

FUT100

FUT089
FUT089-B

C5

FUT092
FUT092-B

FUT088

FUT096
FUT096-B

WL-Box1

FUTD01

Dynamic mode table selection

Select dynamic mode table 1: While the light is in static mode, short press **" S+ "** button 5 times quickly until blue light flashes 3 times slowly.

Select dynamic mode table 2: While the light is in static mode, short press **" S- "** button 5 times quickly until yellow light flashes 3 times slowly.

Dynamic mode table 1 **(default)**

Number	Dynamic Mode	Brightness / Saturation / Speed
1	Mardi Gras	
2	Automatic color change	
3	Sam	
4	Gemstone	
5	Twilight	Adjustable
6	American	
7	Fat Tuesday	
8	Party	
9	Slow Color Splash	

Dynamic mode table 2 **(need to switch manually)**

Number	Dynamic Mode	Brightness / Saturation / Speed
1	Colors gradual change	
2	White light Gradual change	
3	RGB gradual change	
4	Seven colors jump to change	
5	Jump to change randomly	Adjustable
6	Red light gradual change +Flash 3 times	
7	Green light gradual change +Flash 3 times	
8	Blue light gradual change +Flash 3 times	
9	White light gradual change +Flash 3 times	

# DMX512 LED Transmitter Control (Purchased separately)


DMX512 LED Transmitter Link/Unlink

1 Follow instruction of DMX512 transmitter (FUTD01), Choose the zone for the light by pressing " + " or " - " (e.g. "CH12" means zone 12)

Link

The controller is powered off for 10 seconds and then powered on, or press " SET " button 1 time.

Short press "(SET)" 3 times within 3 seconds while the indicator of controller is ON

Link is done once indicator of controller flashes 3 times slowly

Unlink

The controller is powered off for 10 seconds and then powered on, or press " SET " button 1 time.

Short press "(SET)" 5 times within 3 seconds while the indicator of controller is ON

Unlink is done once indicator of controller flashes 10 times quickly

⚠️ If the link or unlink failed, please follow the above steps again.

DND mode ON/OFF (factory default is ON)

Turn ON DND:

Short press "OFF' 3 times within 3 seconds and short press "ON' 3 times, DND mode is activated if the light flashes 4 times quickly

Attention: The status of light (ON or OFF) is same as turn on or off mains

Turn off DND

Short press "ON' 3 times within 3 seconds and short press "OFF" 3 times, DND mode is shut down if the light flashes 4 times slowly

Attention: The light is always ON if turn on or off mains

Connection Diagram

Attention

1.Please ensure that voltage, N and L are correct connection, it will damage the light with wrong wiring

2.Please turn off mains before wiring cable and ensure that connection don't have any problem like short circuit

3.Don't disassemble it if you are not expert

4.Don't use it near magnetic or metal area, it will affect signal and reduce distance.

Made in China