

4. 16 million colors to change, color temperature and brightness adjustable.

2. Digital Display, Set DMX initial address through button.

1. Accord with DMX standard protocol.



3. Support RDM function.

function Beam angle 120°

Support RDM



Dim brightness/

Parameter

Model No.: D5-DW25 Input Voltage: AC100~240V 50/60Hz Power: 25W CRI: >80 PE: >0.5 Luminous Flux: 2000LM Light Efficiency: 80LM/W Color Temperature: 2700K~6500K Beam Angle: 120° Input Signal: DMX, RDM DMX Address: Occupy 5 DMX Address Hole Size: @200~210mm Working Temperature: -10~40°C Material: Al uminum+PC Cover



Installation Tips

Please read instruction before installing it, you can contact with our service center if there is any technical issue



25W RGB+CCT LED Downlight (DMX512&RDM)

Model No · D5-DW25

Features

Saturation

Connection Diagram



Attention: If the DMX downlight is over 32pcs, or using the super long signal cable, you need DMX signal amplifier. Amplify signal cannot be over 5 times.

Function Settings

1.Digital Display status description

Self-locking:

Get into locking state when there is no operation over 10 seconds, digital display with low light.

Unlock: Long press " - " or " + " key 2s to unlock.

Address always ON: DMX signal valid.

Address flickering: DMX signal invalid.

Attention

- 1. This product should be debugged and installed by professionals.
- 2. Please check whether the input voltage meets the requirements of the product voltage range.
- Before switching on the power, please ensure that all wiring is correct, so as not to cause damage to the devices.
- 4. Don't disassemble it if you are not expert

2. DMX initial address setting

Under unlock status, when digital display show 001-512 (000 or example), Short press "-" button or "+" button, you can change the DMX initial address; Long press, you can change it quickly.

For Example: Set Initial address to 100

100	101	102	103	104
R	G	В	CW	WW

Made in China

