

C8 8-Zone RGB+CCT Remote

Model No.:C8

Product Feature

- 2.4G RF wireless transmission technology
- 8-Zone Area countless bulbs for each zone
- MiBoxer/Mi-Light 2.4G series products
- 16 Millions of colors to choose
- RGB, Brightness, color temperature and Saturation adjustable
- Working with multi controllers (control distance 30m)
- Magnetic holder with simple installation



Product Parameter

Product Name: C8 8-Zone RGB+CCT Remote

Model No.: C8

Working voltage: 3V(AAA*2PCS)

Standby consumption: 15μA

Transmitting: 6dBm

Protocol: 2.4GHz RF

Modulation: GFSK

Control Distance: 30M

Working temperature: -10~40°C


EMC standard: ETSI EN 301 489-1 V2.2.3
ETSI EN 301 489-3 V2.3.2

Security standard: EN 61347-2-11:2001+A1: 2019
EN 61347-1: 2015+A1:2021
EN 62493:2015+A1:2022


Radio equipment: ETSI EN 300 400 V2.2.1

Certification: CE、EMC、LVD、RED


Remote



Holder



Indication



Color Ring: adjust RGB color



White light,: Adjust color temperature
RGB: Adjust saturation



Adjust brightness



ALL ON



ALL OFF



White light button



Zone control (Link/Unlink)



Switch to dynamic mode




Dynamic Mode Speed+




Dynamic Mode Speed-

Link/Unlink


Link controller must link with remote before using it



Turn off light 10 seconds and turn on again



Short press "ON" 3 times within 3 seconds




Link is done once light flashes 3 times slowly




Link is failed if light doesn't flash, please repeat above steps
(Attention: can not link again if remote already finished linking)


Unlink:



Turn off light 10 seconds and turn on again



Short press "ON" 5 times within 3 seconds




Link is done once light flashes 10 times quickly



Unlink is failed if light doesn't flash, please repeat above steps
(Attention: no need to unlink if the light never be linked)

Grouping of several lights


You can add an endless numbers of lights to a zone on the 8 channel remote by linking the lights to different zones. This way you are completely flexible in creating different group combinations. Below you can see some grouping examples.




Remark:

Please check the battery installation and controller (totally discharge the power), when you programme after switching off and switching on.

Installation



Remove the sticker on the holder



Stick the holder on the wall and
put remote into it

Attention:

1. Only compatible with Miboxer led controller
2. Don't use it in humidity or high temperature area, please take out battery if don't use it frequently and keep it in dry or static electricity area
3. Don't use it near metal or strong magnetic area, it will affect signal and lost distance.