

100W RGB+CCT Smart LED Garden Light (2.4GHz)

Model No.: FUTC06

Product Feature


- 16 millions color
- Dim RGB/CCT/Brightness, CCT range 2700K-6500K
- 2.4G wireless transmission technology
- One light max work with 12pcs 2.4G RF remote (control distance 30m)
- 18 dynamic mode with jumping and changing gradually (only work with 2,4G RF remote)
- Auto-forwarding: Automatically forward the remote control signal to another master box, making the remote control distance infinite
- Have DND function, usually used in power failure area and save power
- Support TUYA SMART app control (2.4G gateway is needed)
- Support third party voice control like Alexa, Google assistant, Yandex Alice, Tmall Genie, Baidu and Xiaomi
- Working with DMX512 (need DMX512 transmitter)



Product Parameter


Product Name:	100W RGB+CCT Smart LED Garden Light	IP rate:	IP65
Model No.:	FUTC07	Working Temperature:	-10~40℃
Input voltage:	AC100~240V 50/60Hz	Illumination Distance:	>15M
Power:	100W	Dimming Level:	4096
Power factor:	>0.9	Dimming Range:	0.1-100%
CRI:	>80	Dimming Curve:	logarithm
Color temperature:	2700~6500K	EMC Standard (EMC):	ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-3 V2.3.2
Luminous Flux:	7500LM	Security Standard (LVD):	EN 62560:2012+A1; 2015+A11:2019
Luminous efficiency:	75LM/W	Radio equipment (RED):	ETSI EN 300 440 V2.2.1
Beam Angle:	25°	Certification:	CE, EMC, LVD, RED
Protocol:	2.4GHz RF		
Control Distance:	30M		

Dimension



Installation Tips

Please read instruction before installing it, you can contact with our service center if there is any technical issue



For floodlights, waterproof connector required
(Purchased separately)

Lighting source can not be replaced, please buy new light if the light is over lifetime

Auto-forwarding & Auto-synchronization

Remote control signal auto-forwarding

The remote control signal received by the host will be forwarded to another host within 30m, making the control distance infinite.


Dynamic mode auto-synchronization

In the same dynamic mode, the lamps will be automatically synchronized so that the dynamic effects are always consistent.



Link/Unlink


Link Light must link with remote before using it



1
turn off light 10 seconds and turn on again



2
short press " | " 3 times within 3 seconds




3
link is done once light flashes 3 times slowly



Link is failed if light doesn't flash, please repeat above steps
(Attention: can not link again if remote already finished linking)


Unlink:



1
turn off light 10 seconds and turn on again



2
short press " | " 5 times within 3 seconds



3
link is done once light flashes 10 times quickly



Unlink is failed if light doesn't flash, please repeat above steps
(Attention: no need to unlink if the light never be linked)

Compatible Remote (purchase separately)



B8



B0



B3 / B3-B / T3



B4 / B4-B / T4



S2-B / S2-W
S2-G



S2W+



S1W+



FUT100



FUT089
FUT089-B



C5



FUT092
FUT092-B



FUT088



FUT096
FUT096-B



WL-Box1



FUTD01

Dynamic mode table selection

Select dynamic mode table 1: While the light is in static mode, short press “**S+**” button 5 times quickly until blue light flashes 3 times slowly.

Select dynamic mode table 2: While the light is in static mode, short press “**S-**” button 5 times quickly until yellow light flashes 3 times slowly.


Dynamic mode table 1 (default)

Number	Dynamic Mode	Brightness / Saturation / Speed
1	Mardi Gras	Adjustable
2	Automatic color change	
3	Sam	
4	Gemstone	
5	Twilight	
6	American	
7	Fat Tuesday	
8	Party	
9	Slow Color Splash	

Dynamic mode table 2 (need to switch manually)


Number	Dynamic Mode	Brightness / Saturation / Speed
1	Colors gradual change	Adjustable
2	White light Gradual change	
3	RGB gradual change	
4	Seven colors jump to change	
5	Jump to change randomly	
6	Red light gradual change +Flash 3 times	
7	Green light gradual change +Flash 3 times	
8	Blue light gradual change +Flash 3 times	
9	White light gradual change +Flash 3 times	

DMX512 LED Transmitter Control (Purchased separately)





DMX512 LED Transmitter Link/Unlink

- 1 Follow instruction of DMX512 transmitter (FUTD01), Choose the zone for the light by pressing “+” or “-” (e.g. “CH12” means zone 12)



2



4

Link

The controller is powered off for 10 seconds and then powered on, or press “SET” button 1 time.

Short press “SET” 3 times within 3 seconds while the indicator of controller is ON

Link is done once indicator of controller flashes 3 times slowly

Unlink

The controller is powered off for 10 seconds and then powered on, or press “SET” button 1 time.

Short press “SET” 5 times within 3 seconds while the indicator of controller is ON

Unlink is done once indicator of Light flashes 10 times quickly



If the link or unlink failed, please follow the above steps again.

DND mode ON/OFF (factory default is ON)

Turn ON DND:

Short press "OFF" 3 times within 3 seconds and short press "ON" 3 times, DND mode is activated if the light flashes 4 times quickly


Attention: The status of light (ON or OFF) is same as turn on or off mains

Turn off DND

Short press "ON" 3 times within 3 seconds and short press "OFF" 3 times, DND mode is shut down if the light flashes 4 times slowly

Attention: The light is always ON if turn on or off mains

Connection Diagram



Attention

- 1.Please ensure that voltage, N and L are correct connection, it will damage the light with wrong wiring
- 2.Please turn off mains before wiring cable and ensure that connection don't have any problem like short circuit
- 3.Don't disassemble it if you are not expert
- 4.Don't use it near magnetic or metal area, it will affect signal and reduce distance.



Made in China