


Panel Controller

Model No.: P1 / P2

I. Features

This product is touch panel controller designed with standard 86*86mm-box structure which can be connected with constant voltage LED strip or lamp. You can pairt it with remote control and enjoy remote control function. It's flexible and convenient to use.





Panel Controller (Single Color)

Model No.: P1

Panel Controller (Single Color)

Panel Controller (Color Temp.)

Input/Output Voltage: DC12V~24V RF: 2.4GHz

Model No.: P1

Input/Output Voltage: DC12V~24V RF: 2.4GHz

Dimmable control

2.4G RF wireless

2.4G transmission technology Remote control Control distance 30m

Model No.: P2

Output: 5A/Channel

Total Output Max: 10A

60S Delay OFF

Mode 60S

Panel Controller (Color Temp.)

Save1 Save2

Model No.: P2

Color temperature

2700K~6500K

2.4G RF wireless transmission technology

Support third party voice control

(2.4GHz gateway is needed)

Output: 5A/Channel Total Output Max: 10A

Control Distance: 30m Working Temp.: -20~60°C



Smartphone APP control (2.4GHz gateway is needed)



Support third party voice control (2.4GHz gateway is needed)



60S | 60S Delay OFF

Control Distance: 30m

Working Temp.: -20~60°C

Remote control Control distance

Dimmable control

Smartphone APP control

(2.4GHz gateway is needed)

Control distance 30m

- 1. Short press ON / OFF switching
- 2. Long press to turn on night light while light is on.
- 3. Short press twice to enter the learning code state (see 5 for details) while light is on.



- I. When the light is ON, Press " 60S ", the light will be off automatically after 60 seconds.
- 2. When light is OFF, long press 5 seconds to turn ON the




. Press mode shortly, switch to next mode. 9 modes switching. Long press "Mode" to exit dynamic mode.

indicating sound.

Touch dimming slider to change the brightness from 1%~100%.

2. Function



P1 Button Function







- indicating sound.



- 2. When light is OFF, Long press 5 seconds to turn OFF the




P2 Button Function



- Long press to turn on night light while light is on.
- 3. Short press twice to enter the learning code state
- (see 5 for details) while light is on. When the light is ON, press " 60S ", the light will be off
- automatically after 60 seconds.

Mode Press mode shortly, switch to next mode; 9 modes switching.





1. Press " Save1 " shortly, select save1 mode; long press " Save1 ", save present mode to save1.


2. When light is OFF, long press 5 seconds to turn OFF the indicating sound.


Save2 1. Press "Save2" shortly, select save2 mode; long press "Save2 ". save present mode to save2.

> 2. When light is OFF, long press 5 seconds to turn ON the indicating sound.

3. Link/Unlink

Compatible with these remote controls (Purchase separately)





Light will work after linking with remote control; for more details, pls read the remote instruction.

4. P1 / P2 Dynamic Mode table

State	Number	Mode	Brightness
	1	Gradual change fast	
	2	Gradual change in middle speed	
	3	Gradual change Slowly	
P1/P2	4	Jump to change Fast	
Dynamic Mode	5	Jump to change in middle speed	Adjustable
	6	Jump to change slowly	
	7	Blinks fast	
	8	Blinks in middle speed	
	9	Blinks slowly	

5. Remote control Link/Unlink

Support all remote control to do Link/Unlink (see 3 for details)



Link

continuously when light is on

Press the remote control within 3 seconds " I " kev 3 times

The light blink 3 times slowly means the linking is done successfully

Unlink

Press "(b) " 2 times continuously when liaht is on

Press the remote control within 3 seconds " I " kev 5 times

The light blinking 10 times quickly means the unlinking successfully

If the link or unlink failed, please follow the above steps again.

6. Signal transmitting


One controller can transmit the signals from the remote control to another controller within 30m, as long as there is a controller within 30m. the remote control distance can be limitless.

7. Modes synchronization

Different controllers can work synchronously when they are started at different times, controlled by the same remote, under same dynamic mode and within 30m distance.



The same dynamic mode, the same speed can be synchronized.



8. PWM high frequency / low frequency switching


Switch to high frequency (8KHz): on the condition of turning on the light

- 1. Short press the "OFF" button of the remote control once:
- 2. Short press the "ON" button of the remote control 5 times within 3 seconds, the white light blink 2 times quickly, indicating successfully.


Switch to low frequency (500Hz): on the condition of turning off the light

- 1. Short press the "ON" button of the remote control once:
- 2. Short press the "OFF" button of the remote control 5 times within 3 seconds, the white light blink 2 times slowly, indicating successfully


9. Installation / Dismantlement




Install the bottom case into the wall: Above are the standard bottom cases.



Fix the controller base on the bottom case with screw.



Clicks into the upper side of glass panel on the controller base, then press the lower side slightly to make it clicks into the controller base.



Plug into the below bayonet with a screwdriver, and upwarp screwdriver, then you can dismantle the controller.

Attention:

- 1. Please check whether the voltage of the power supply is in accordance with the controller, and please check the connection of both the cathode and anode, otherwise the controller will be broken.
- 2. Please don't connect wires with power on. Please turn on again only when it is in right connection and no short circuit.
- 3. Please do not use the controller in the place with widely range metal area or strong electromagnetic wave nearby, otherwise, the remote distance will be seriously affected .

