

AC Triac Dimmer (2.4G + Push)

Model No.: TRI-C1

Contents

<u>Feature</u>	2
<u>Parameter</u>	3
<u>Connection Diagram</u>	4
<u>Installation Diagram</u>	5
<u>PUSH Dimming</u>	5
<u>Remote control instruction</u>	6-9
<u>Attention</u>	10

1. Feature

Don't need signal cable and change original wire layout, it's very simple to install it with low cost. Mini appearance can fit for EU/USA standard junction box. Wide application for single color triac LED lights, filament lamps, Halogen lamps.

- Smartphone APP control (need to buy 2.4GHz gateway)
- 2.4G RF wireless remote control
- Push dimming function
- Trailing edge phase-cut technology
- 0~100% stepless dimming and flicker free
- Lowest brightness setting function
- Built-in temperature detecting switch, over heat /loading protection
- Auto transmitting function, unlimited control distance
- Screw connector is reliable and easy to do installation
- Anti-fire PC shell is more safety

2. Parameter

Model No.: TRI-C1

Input Voltage: 100-240V~ 50/60Hz

Output Voltage: 100-240V~


Output Current: Max 1.36A

Output Power: 150W @110V; 300W @220V


Dim Method: RF wireless dimming

Working Temperature: -10~40°C

Control Distance: 30m



3. Connection Diagram



Attention

Please check and ensure that all cable had done correct connection before turn on it, otherwise the dimmer is easy to be damaged.

“Breaker mode” is activated or shut down



Attention: It only support to turn on/off light, user can not dim device once this mode is activated

Turn On: short press “SET” 5 times quickly, mode had activated once indicator blink 3 times quickly

Turn Off: short press “SET” 5 times quickly, mode had shut down once indicator flash 3 times slowly

4. Installation Diagram

Support following standing junction box



5. PUSH Dimming

Short press PUSH switch:

Turn ON/OFF light

Long press PUSH switch:

- Stepless dimming brightness.
- Long press and release your finger, then repeat long pressing to increase or decrease brightness
- Please long press switch 20 seconds until all lights have same brightness with 100% level if multi dimmers had connect with same self-return switch. The quantity of dimmers which connect with same self-return switch can not be over 25 pieces, the connection cable of self-return switch can not be over 20m.

6. Remote control instruction

6.1. Link remote


For K1 remote

1). Learning code


Way 1: short press "SET" one time, Indicator breathes

Way 2: power off dimmer 10 seconds and power on again

Way 3: short press Push switch (ON- OFF)




2). Press "SET" 3 times within 3 seconds, linking code is done once the light flashes 3 times slowly



For other remote


1). Learning code

2). Press "I" any "ON" button in group zones 3 times within 3 seconds, linking code is done once the light flashes 3 times slowly




6.2. Unlink with remote

Long press the "SET" key for 3 seconds, the indicator will flash 10 times quickly, code cleared successfully.




For K1 remote

- 1). Learning code
- 2). Press "SET" 5 times within 3 seconds, unlinking is done once the light flashes 10 times quickly



For other remote

- 1). Learning code
- 2). Press " | " any "ON" button in group zones 5 times within 3 seconds, unlinking is done once the light flashes 10 times quickly



6.3. Compatible remote (purchase separately)



FUT006



FUT007



B1 / B1-B / T1



B2 / T2



K1 / K1-B



FUT087 / FUT087-B



S1-B / S1-W / S1-G



WL-Box1

6.4. Set up min brightness with remote

 This function should be paired with remote firstly before setting.

For K1 remote

- 1). Long press "SET" 3 seconds until the light flashes one time, indicator is going into flashing status
- 2). Short press "SET" to get 10 kinds of brightness: 3%, 5%, 7%, 9%, 12%, 17%, 22%, 28%, 34%, 40%
- 3). Short press rotating button to confirm setting or waiting for 10 seconds to be confirmed automatically, the light will recover brightness to previous level.

For other remote


- 1). Long press the "OFF" button on the remote or "○" button on the zone, until the light flashes one time, indicator is going into flashing status
- 2). Short press the "OFF" button on the remote or "○" button on the zone to set up 10 different brightness (3%, 5%, 7%, 9%, 12%, 17%, 22%, 28%, 34%, 40%)

Short press any button except "OFF" to confirm setting or waiting for 10 seconds to be confirmed automatically, the light will recover brightness to previous level

Attention: Master OFF button can set up lowest brightness for all connected dimmer

6.5. Auto transmitting

One light can transmit the signals from the remote control to another light within 30m, as long as there is a light within 30m, the remote control distance can be limitless.



Attention: All dimmer must link with same remote

7. Attention

1. Please turn off power supply before installation.
2. Please ensure input voltage to be same as requirements from device.
3. Don't disassemble device if you are not expert, otherwise it will damage it.
4. Please do not use the light in the place with widely range metal area or strong electromagnetic wave nearby, otherwise, the remote distance will be seriously affected.

Made in China



Dimmer can not use in humid area