

50W RGB+CCT Smart LED Garden Light (2.4GHz)

Model No : FUTCO6

Product Feature

- 16 millions color
- Dim RGB/CCT/Brightness, CCT range 2700K-6500K
- · 2.4G wireless transmission technology
- . One light max work with 12pcs 2.4G RF remote (control distance 30m)
- 18 dynamic mode with jumping and changing gradually (only work with 2,4G RF remote)
- Auto-forwarding: Automatically forward the remote control signal to another master box, making the remote control distance infinite
- Have DND function, usually used in power failure area and save power
- Support TUYA SMART app control (2.4G gateway is needed)
- Support third party voice control like Alexa, Google assistant, Yandex Alice, Tmall Genie, Baidu and Xiaomi
- Working with DMX512 (need DMX512 transmitter)



Product Parameter

50W RGB+CCT Smart LED Garden Light	IP rate:	IP65
FUTC06	Working Temperature:	-10~40℃
AC100~240V 50/60Hz	Illumination Distance:	>15M
50W	Dimming Level:	4096
>0.9	Dimming Range:	0.1-100%
>80	Dimming Curve:	logarithm
2700~6500K	EMC Standard (EMC):	ETSI EN 301 489-1 V2.2.3 ETSI EN 301 489-3 V2.3.2
4000LM		
80LM/W	Security Steed dead (N/D)	EN 62560:2012+A1; 2015+A11:2019
25°	Security Standard (LVD) :	
2.4GHz RF	Radio equipment (RED) :	ETSI EN 300 440 V2.2.1
30M	Certification:	CE, EMC, LVD, RED
	FUTC06 AC100~240V 50/60Hz 50W >0.9 >80 2700~6500K 4000LM 80LM/W 25* 2.4GHz RF	FUTCO6 Working Temperature: AC100~240V 50/60Hz Illumination Distance: 50W Dimming Level: > 0.9 Dimming Range: > 80 Dimming Curve: 2700~6500K EMC Standard (EMC): 4000LM Security Standard (IVD): 25° 2.4GHz RF Radio equipment (RED):


Dimension





Installation Tips

Please read instruction before installing it, you can contact with our service center if there is any technical issue



For floodlights, waterproof connector required (Purchased separately)

Lighting source can not be replaced, please buy new light if the light is over lifetime

Auto-forwarding & Auto-synchronization

Remote control signal auto-forwarding

The remote control signal received by the host will be forwarded to another host within 30m, making the control distance infinite.


Dynamic mode auto-synchronization

In the same dynamic mode, the lamps will be automatically synchronized so that the dynamic effects are always consistent.




Link/Unlink

Link Light must link with remote before using it







turn off light 10 seconds and turn on again


short press " | " 3 times within 3 seconds

link is done once light flashes 3 times slowly



Link is failed if light doesn't flash, please repeat above steps (Attention: can not link again if remote already finished linking)

Unlink:



turn off light 10 seconds and turn on again



short press " | " 5 times within 3 seconds




link is done once light flashes 10 times quickly



Unlink is faild if light doesn't flash, please repeat above steps (Attention: no need to unlink if the light never be linked)

Compatible Remote (purchase separately)



Dynamic mode table selection

Select dynamic mode table 1: While the light is in static mode, short press "**S+**" button 5 times quickly until blue light flashes 3 times slowly.

Select dynamic mode table 2: While the light is in static mode, short press "S-" button 5 times quickly until yellow light flashes 3 times slowly.


Dynamic mode table 1 (default)

Number	Dynamic Mode	Brightness / Saturation / Speed	
1	Mardi Gras		
2	Automatic color change		
3	Sam		
4	Gemstone		
5	Twilight	Adjustable	
6	American		
7	Fat Tuesday		
8	Party		
9	Slow Color Splash		

Dynamic mode table 2 (need to switch manually)

Number	Dynamic Mode	Brightness / Saturation / Speed	
1	Colors gradual change		
2	White light Gradual change		
3	RGB gradual change		
4	Seven colors jump to change		
5	Jump to change randomly	Adjustable	
6	Red light gradual change +Flash 3 times		
7	Green light gradual change +Flash 3 times		
8	Blue light gradual change +Flash 3 times		
9	White light gradual change +Flash 3 times		


DMX512 LED Transmitter Control (Purchased separately)



DMX512 LED Transmitter Link/Unlink

Follow instruction of DMX512 transmitter (FUTD01), Choose the zone for the light by pressing
"+" or "-" (e.g. "CH12" means zone 12)

Follow instruction of DMX512 transmitter (FUTD01), Choose the zone for the light by pressing





Link

The controller is powered off for 10 seconds and then powered on, or press "SET" button 1 time.

Short press "FT" 3 times within 3 seconds while the indicator of controller is ON

Link is done once indicator of controller flashes 3 times slowly

Unlink

The controller is powered off for 10 seconds and then powered on, or press "SET" button 1 time.

Short press "⊕" 5 times within 3 seconds while the indicator of controller is ON Unlink is done once indicator of Light flashes 10 times quickly



If the link or unlink failed, please follow the above steps again.

DND mode ON/OFF (factory default is ON)

Turn ON DND:

Short press "OFF' 3 times within 3 seconds and short press "ON' 3 times, DND mode is activated if the light flashes 4 times quickly


Attention: The status of light (ON or OFF) is same as turn on or off mains

Turn off DND

Short press "ON' 3 times within 3 seconds and short press "OFF" 3 times, DND mode is shut down if the light flashes 4 times slowly

Attention: The light is always ON if turn on or off mains

Connection Diagram



Attention

- 1. Please ensure that voltage. N and L are correct connection, it will damage the light with wrong wiring
- 2.Please turn off mains before wiring cable and ensure that connection don't have any problem like short circuit
- 3.Don't disassemble it if you are not expert
- 4.Don't use it near magnetic or metal area, it will affect signal and reduce distance.

